


Wolf Creek Dam Failure Inundation



Legend

Inundation area under Emergency Condition RED


Inundation area under Emergency Condition BLUE

Inundation area under Emergency Condition GREEN

County Boundary Lines

Map Grid

Map Scale



Please Note

The flooded areas shown on this map are estimates for Emergency Evacuation Planning and Execution. Actual flooding heights may vary by +/- 15 feet.

Definition of Terms

River Mile -- The distance along the channel of the Cumberland River upstream from its mouth at the Ohio River.

Arrival Time -- Amount of time after an assumed event until water begins to rise at a location.

Rate of Rise -- Rate at which water will rise at a location after the arrival time.

Dam Failure -- Any condition resulting in the uncontrolled release of water other than over or through a controlled spillway or outlet works.

